

# Classic cantilever ASSEMBLY INSTRUCTION

1		2			3	
① BACK&SEAT CUSHION	② ARMREST	③ CANTI BASE	④ SCREW M8*40	⑤ SCREW M8*20	⑥ ALLEN KEY	⑦ PLASTIC CAP
1 PC	1 PAIR	1 PC	4 PCS	4 PCS	1 PC	4 PCS

IMPORTANT NOTE - PLEASE ASSES ALL COMPONENTS PRIOR TO DISPOSAL OF PACKAGING AND ASSEMBLY OF CHAIR