

## Impulse Universal Straight/ Wave Desk.

- End Leg to Modesty panel bolts and locking barrels.

(Requires 4 bolts and 4 barrels)

(There should also be 4 bolts pictured on the right to attach the legs to the top panel.)



- Modesty panel to the top panel

(Requires 2 Cam Pins and 2 Cam Locks)

