

MIRAGE II HEADREST ASSEMBLY INSTRUCTION

| | | | |
|------------|------------|------------------|-------------|
| | | | |
| ① BACKREST | ② HEADREST | ③ SCREW M5*14 | ④ ALLEN KEY |
| | | | |
| 1 PC | 1 PC | 2 PCS | 1 PC |

IMPORTANT NOTE - PLEASE ASSES ALL COMPONENTS PRIOR TO DISPOSAL OF PACKAGING AND ASSEMBLY OF CHAIR