

Madrid Assembly Guide

Step 1)

Line up both rear and front leg on one side and insert 2 x 75mm bolts with washers into back cushion and touch tighten
(Please note both front and rear legs are handed to ensure the recessed holes are facing outward)

Step 2)

Insert the 4 x nuts into the seat shelf, ensuring the minus head is facing outwards, twist until the receiving hole is in the correct position.

Step 3)

While ensuring the seat shelf is facing the correct way up (with the label facing downwards and the recessed holes facing upwards), place in position against the rear legs with the dowels inserted, the remaining 75mm bolts with washers can then be inserted through the legs and arms and into the back cushion and touch tightened as per step 1.



Step 4)

Insert 4 x 65mm bolts into the 4 holes around the bottom of the legs and touch tighten to bring frame together.

Once the frame is assembled as per the image, securely tighten all 8 bolts to complete frame assembly.



Step 6)

Line up the underside of the seat with the holes in the frame and secure using 2 x 65mm bolts with washers.



Step 7)

All done! The chair is now fully assembled and ready to use.

