

Impulse Universal Crescent Desk.

- End Leg to Modesty panel bolts and locking barrels.

(Requires 4 bolts and 4 barrels)

(There should also be 5 bolts pictured on the right to attach the legs to the top panel.)



- Modesty panel to the top panel

(Requires 4 Cam Pins and 4 Cam Locks)



- Middle Support leg Bolts and middle post.

(Requires 4 Bolts and 4 Barrels)

