











Setup Guide
 Manuel de configuration
 设定指南

Setup Guide / セットアップガイド / 安装指南 /
 دليل الإعداد / 설치 가이드 / Guía de configuración /
 Guide d'installation / Installatiehandleiding /
 Einrichtungshandbuch / Guia de configuração /
 Guida di installazione / Startguide /
 Installationsvejledning / Asetusopas /
 Innstillingsveiledning / Przewodnik ustawień /
 Průvodce nastavením / Sprievodca nastavením /
 Beállítási útmutató / Ghid de configurare /
 Ръководство за настройка / Οδηγός
 εγκατάστασης / Seadistusjuhend /
 Uzsākšanas ceļvedis / Nustatymo vadovas /
 Priročnik za pripravo / Vodič za postavljanje /
 Vodič za podešavanje / מודריך הגדרה




3






*1 (PC) (电脑) / (PC)

4



5



https://rd1.sony.net/help/tv/27q10s/h_zz/

出版日期：2024 年 9 月