


Wire basket mounting

Please note that the same bracket is used for both under desk (top) and modesty panel (H) fixing



If extra space is needed to access sockets etc, the basket may be moved to position 5 whilst access is required. Always return to position 3 when work is completed

