



Chroma Power module


Top Fix 30 and 60 degree




Step 1




Step 2




Step 3





Under desk fixing 30 and 60 degree



Under desk and top fixing



30 and 60 degree positioning



To change the fuse, please TURN ELECTRICITY OFF and wait for 10 minutes before operating. Use a flat screwdriver (5mm width) to pull out carrier with fuse and replace with spare one.