




Setup - ABC Wireless keyboard and mouse user instructions



Features

- Advanced 2.4GHz wireless with long-range connection eliminates delays, drop-outs and interference.
- Smart battery system with multiple battery-save modes including sleep when idle.
- Receiver stowed in mouse for transportation.
- Requires 1x AAA battery for mouse and 2x AAA for keyboard.

Installation

1. Slide open mouse battery cover, remove wireless receiver and insert into free USB slot in computer.
2. Insert 1x AA battery into mouse(negative end first), replace battery cover and switch on.
3. Remove battery cover on underside of keyboard.
4. Insert 2x AAA battery and replace battery cover.

System compliace

Windows ME/2000/XP/Vista/7/Android OS

Troubleshooting

Q1: No reaction from keyboard or mouse A1: Check battery polarity, Check on/off switch.

Q2: Mouse laser light off or flashing.
A2: Change to suitable mousing surface. Clean lens on underside of mouse.

Important

- Exterior of mouse and keyboard may be cleaned with dry, clean cloth.
- Uneven surface may not be suitable for mouse tracking.
- Do not disassemble mouse or keyboard for maintenance.
- Remove battery if mouse and keyboards are not to be used for long periods of time.
- Do not use Bluetooth devices in close proximity to wireless set.
- At end of product life, please dispose of this product in accordance with local regulations .