How to set-up your Piano II BT wireless keyboard





CONNECTING:
Flashing Blue LED light
POWER LOW
Flashing Blue LED light

COMPATIBILITY

1. Compatible with Windows and Mac OS
2. Android Handhelds
3. Apple iPad, iPhone/touch in 4.0 OS(and above)
4. Android Tablets V:4.1.1

Remark

If your computer doesn't have the built-in Bluetooth function, please make sure that you have a Bluetooth dongle that supports Bluetooth version 2.0 and above.

Features / Specifications

• Bluetooth 2.0 and 3.0 compatible
• Windows and Mac compatible
• 78-key scissor low-profile design
• Built-in intelligent power management software for power conservation
• Supports: Windows 2000 / XP / 7 / 8 / 10 and Mac OSX
• Working range: 10 meters
• Requires: 2x AAA batteries
• Dimensions: 28.5 x 12.2 x 2 cm

Installing the battery

1.Open the battery compartment on the rear of the keyboard.
2. Insert 2x AAA. Make sure to comply with the polarity markings.
3. Close the battery compartment.
4. Switch the power to the ON position and connect to the computer.

Connecting your Bluetooth device

• Before using Bluetooth devices for the first time, you must connect your devices through a standard discovery and pairing process. Before installation, please make sure the keyboard is switched ON.

• Press the CONNECT button, you will see the LED indicator flashing to indicate you are in discovery and pairing mode, then you are ready to connect the keyboard to your Bluetooth device. Then follow the steps described above to pair with Windows / PC / Apple IOS / Android.

POWER LOW INDICATOR

The LED indicator flashes BLUE when the battery power is low. Replace both batteries at the earliest opportunity to prevent power interruption.

Using the Bluetooth keyboard

The keyboard is designed with the following power management features to conserve battery power.

Power saving mode

If the keyboard is not used for 10 minutes, the device will go into sleep mode automatically.

Reconnecting the keyboard to the system

When the keyboard is reactivated, it automatically reconnects itself to the Bluetooth system. The process may take less than a second to up to a minute, depending the system environment. During the reconnect mode, the connection indicator flashes BLUE until the keyboard and the system connections are established. Keyboard goes through the same process everytime the computer/Bluetooth are powered on. This is not an error, it is the nature of the Bluetooth connectivity.

standivarius