

# StarTech\_com Hard-to-find made easu

## Thunderbolt 3 Dual PCIe 3.0 Expansion Chassis - 8K 60Hz DisplayPort







## **Package Contents**

- TB3 PCIe Expansion Chassis x1
- Power Adapter x1
- Ouick-Start Guide x1
- 3.3ft (1m) Thunderbolt Host Cable x1
- Footpad Set x1

Component		Function		
1	Power LED Indicator	<ul> <li>Indicates if the TB3 Expansion Chassis is Receiving Power from the 12V DC Power Port</li> </ul>		
		Solid Blue - Receiving Power		
		Off - Not Receiving Power		
2	2x PCI-Express (PCIe) Expansion Slots	Install up to two PCIe Cards		
		Supports half-length single-slot PCIe cards with full profile brackets		
		• PCle 3.0 x4 (2700 MB/s)		
		PCle x16 Card Sizes Supported at PCle x4 Speeds		
3	2x Thumb Screws	<ul> <li>Loosen Counter-Clockwise to Release the PCIe Card Drawer from the Enclosure</li> </ul>		
		Tighten Clockwise to Secure the PCle Card Drawer into the Enclosure		
4	12V DC Power Port	Connect to the Included Power Adapter from an AC     Power Source		
5	DisplayPort Video Output Port	Connect to a DisplayPort Display		
		• DisplayPort 1.4		
		<ul> <li>Up to 8K (7680 × 4320) 60Hz / 4K (3840 X 2160) 144Hz Resolutions</li> </ul>		
6	2x Thunderbolt 3 Ports (USB-C)	<ul> <li>Connect to a an Upstream Thunderbolt Host Device or Downstream Thunderbolt Peripheral/Display</li> </ul>		
		Thunderbolt 3		
		40Gbps Thunderbolt Communication		
		• 10Gbps USB 3.2 Gen1 Communication		
		<ul> <li>Up to 6K (6144 × 3160) 60Hz / 5K (5120 × 2880)</li> <li>60Hz Resolutions</li> </ul>		
		DisplayPort 1.4 Alt Mode		
		<ul> <li>Up to 8K (7680 × 4320) 60Hz / 4K (3840 X 2160) 144Hz Resolutions</li> </ul>		

## **Requirements**

- Up to two PCIe Card(s) Thunderbolt 3 Enabled Host Computer
- Phillips Type Screwdriver

For the latest drivers, manuals, product information, technical specifications, and declarations of conformance, please visit: www.StarTech.com/2TBT3-PCIE-ENCLOSURE

To view manuals, FAQs, videos, drivers, downloads, technical drawings, and more, visit www.startech.com/support.

## **PCIe Power Management Notice - ALWAYS ON:**

The PCIe bus on the **2TBT3-PCIE-ENCLOSURE** will **ALWAYS** provide power to the connected PCIe cards, therefore high-power peripheral cards (audio/video encoders/ decoders, MCU enabled, PoE, USB, etc.) could continue to draw a load while the host is disconnected, off, sleeping, or hibernating. To ensure that connected peripherals do not draw an unintended load it is strongly recommended to unplug the power to the chassis while not in use.

## Installation

### **PCIe Card Installation**

- 1. Place the TB3 PCIe Expansion Chassis on a surface with Side A facing downward, and the **Thumbscrews** located on **Side B** facing upwards.
- 2. Turn the **Thumbscrews** counter-clockwise to release the PCIe Card Drawer from the Enclosure.
- 3. Bracket Plates cover each of the PCIe Expansion Slots. Identify the Bracket Plate(s) covering the PCIe Expansion Slot(s) where the PCIe Card(s) will be installed.
- Remove the Screw(s) holding the Bracket Plate(s) in place, using a Philips Type 4. Screwdriver.
- 5. Gently detach the Bracket Plate(s) from the PCle Expansion Slot(s).
- Insert the PCIe Card(s) into the corresponding PCIe Expansion Slot(s), ensuring they are properly aligned.
- 7. Reinstall the Screw(s) removed in step 3, using a **Philips Type Screwdriver**, to secure the PCIe Card(s) into place.
- 8. (Optional) If the PCIe Card(s) requires power, connect the PCIe Card's Power Input to the 12V SATA Power Output(s), located on the PCIe Card Drawer, using a SATA Power Cable or SATA Power Adapter (not included).
- 9. Slide the PCIe Card Drawer back into the Enclosure.
- 10. Turn the **Thumbscrews** clockwise to secure the PCIe Card Drawer into the Enclosure.

#### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of thirdparty companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

#### Warranty Information

This product is backed by a 2-year warranty.

For further information on product warranty terms and conditions, please refer to www.startech.com/warranty.

#### Limitation of Liability

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.

StarTech.com Ltd. 45 Artisans Cres London, Ontario NSV 5E9 Canada	StarTech.com LLP 4490 South Hamilton Road Groveport, Ohio 43125 U.S.A.	StarTech.com Ltd. Unit B, Pinnacle 15 Gowerton Rd, Brackmills Northampton NN4 7BW United Kingdom		FR: startech.com/fr DE: startech.com/de ES: startech.com/es NL: startech.com/it JP: startech.com/it JP: startech.com/jp
--	---	--	--	--

# Connect a Display to the DisplayPort Video Output Port on the TB3

### **PCIe Expansion Chassis**

1. Connect a DisplayPort enabled Display Device to the **DisplayPort Video Output** Port on the TB3 PCIe Expansion Chassis, using a DisplayPort Cable (sold separately).

### Connect a Thunderbolt 3 Peripheral/Display to the Thunderbolt 3 Port on the PCIe Expansion Chassis

- 1. To connect a Thunderbolt Peripheral: Connect the Thunderbolt Peripheral to either of the Thunderbolt 3 Ports on the TB3 PCIe Expansion Chassis, using a Thunderbolt 3 cable (sold separately).
- 2. To connect a Display: If using a Display with a USB-C or Thunderbolt 2/3 input, connect the Display to either of the **Thunderbolt 3 Ports** on the **TB3 PCIe Expansion Chassis**, using the required cabling. For other displays, connect a USB-C Video Adapter (HDMI, DisplayPort or VGA, sold separately) from the Thunderbolt 3 **Port** on the TB3 PCIe Expansion Chassis to the Display.

### **Connect the TB3 PCIe Expansion Chassis to a Host Computer**

- 1. Connect the 12V DC Power Port on the TB3 PCIe Expansion Chassis to an AC Outlet, using the included **Power Adapter**.
- 2. Connect a Thunderbolt 3 Port on the Host Computer to either of Thunderbolt 3 Ports on the TB3 PCIe Expansion Chassis, using the included 3.3ft (1m) Thunderbolt Host Cable.

**Note:** There are no drivers required for the TB3 PCIe Expansion Chassis. However, drivers may be required for the PCIe Card(s) installed within. For more information about whether the installed card(s) require drivers or additional installation steps, see the documentation that came with the PCIe card(s) or contact the manufacturer.





Privilégiez la réparation ou le don de votre appareil

### **Regulatory Compliance**

#### FCC - Part 15

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by StarTech.com could void the user's authority to operate the equipment.

#### Industry Canada Statement

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe [B] est conforme à la norme NMB-003 du Canada.

CAN ICES-3 (B)/NMB-3(B)

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

(1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.